


# FRAME HEATER

(Model: 6AG)


## User Manual



## 1-Characteristics

Rated Voltage	220VAC±10% 50/60Hz or 110VAC±10% 50/60Hz		
Working Temperature	150°C (HotII)	Rated Power	650W (HotII)
Wind Speed	2.0 m/s	Fan Power	5W
Optional Setting	Cool、 Hot I 、 HotII		

## 2-Switch Icon



**OFF:** Power Off

**COOL:** Cool Wind

**I :** Low Temperature

**ON:** Power On

**HOT:** Hot Wind

**II :** High Temperature

\* Only when the switch are in the grade HOT, I /II setting will be effective.

## 3-Caution

1. Please ensure that the air inlet and outlet are not blocked before use;
2. It should be placed on a horizontal workbench during use;
3. The continuous heating time of grade II cannot exceed 60 minutes;
4. Do not use water, water into the air outlet will lead the circuit problem.